

SCOSCHE

US2B

UNIVERSAL CD SWITCHER

Dual input, single output switcher



NOTE: Trigger amplifier with main source unit. Leave main source unit on while operating auxiliary source unit, so that the amplifier will stay on.

©2010 SCOSCHE INDUSTRIES, INC.

SI 6/10 300US2B

SCOSCHE

US2B

UNIVERSAL CD SWITCHER

Dual input, single output switcher



NOTE: Trigger amplifier with main source unit. Leave main source unit on while operating auxiliary source unit, so that the amplifier will stay on.

©2010 SCOSCHE INDUSTRIES, INC.

SI 6/10 300US2B

SCOSCHE

US2B

UNIVERSAL CD SWITCHER

Dual input, single output switcher



NOTE: Trigger amplifier with main source unit. Leave main source unit on while operating auxiliary source unit, so that the amplifier will stay on.

©2010 SCOSCHE INDUSTRIES, INC.

SI 6/10 300US2B

SCOSCHE

US2B

UNIVERSAL CD SWITCHER

Dual input, single output switcher



NOTE: Trigger amplifier with main source unit. Leave main source unit on while operating auxiliary source unit, so that the amplifier will stay on.

©2010 SCOSCHE INDUSTRIES, INC.

SI 6/10 300US2B